

Proper maintenance and record keeping are the keys to keeping your equipment in top condition and also to ensure that you are in compliance with Crysteel's industry-leading 5-year warranty.

Some tips and advice for proper body maintenance include:

BODY MAINTENANCE

- Lubricate all grease fittings each time the truck is serviced, every 100 cycles, or every month, whichever comes first. *Some grease zerks may be in hard to find spots.
- Check all bolts and fasteners regularly



IMPORTANT SAFETY TIPS WHEN PERFORMING MAINTENANCE ON YOUR EQUIPMENT:

- Always carefully block up the body, using the body prop, before working under it.
- Do not load the hoist beyond its capacity.
- Document all maintenance performed

****This list is not intended to be all-inclusive or include enough detail for every Crysteel product. It is merely intended to highlight some primary areas of maintenance. Improper maintenance of the dump body and systems can cause functional issues that may lead to damage of components, bodily injury, and/or death.**



HOIST MAINTENANCE

- Lubricate all grease fittings each time the truck is serviced, every 100 cycles, or every month, whichever comes first.

**Some grease zerks may be in hard to find spots.*

ELECTRIC POWER UNIT MAINTENANCE:

- Use the proper hydraulic fluid; keep it clean, check it regularly, and change it annually.
- Breather cap should be cleaned with each change.
- If you are working in very dusty / dirty environments, change the hydraulic fluid and clean the breather cap more often.
- Be sure to keep the oil clean by using clean containers, funnels and other equipment.
- Use automatic transmission fluid (Dexron II or III) in the electric power unit.
- Do not overfill the reservoir.
- Never use hydraulic brake fluid in the hydraulic system.
- Do not tamper with the hydraulic relief valve. This will cause severe damage to the hoist and cylinder, and will void your Crysteel Warranty.
- Be sure to check all bolts and fittings regularly, and keep them tight.